

1. включить воздух 'давление не ниже 0,5 МПа)
2. включить осн. рубильник (красный)
3. нажать STOP (2 раза)
4. своей рукой убрать пластины в иск. положении (приоткрытые фазы)

### Пульт

#### 1) выбор программы

М/С программа запускается в меню где выбираем номер памяти (1, 2, 3)

ENT - ввод памяти

програм. выбираем стрелками  
нажимаем ENT (активируется - в первом квадрате)

#### 2) параметры программы

→ F2 - закрывка (меню)

→ ENT - поменять цифрами

F3 - длина строчки

ENT, цифры, ENT

F6 - подсветка

BACK - сброс

P - включение параметров шитья

↓ (прорубка, ...)

Sewing Functions:

### 2.1.5 Name seams

To be able to distinguish seams, it is possible to define seam names. Follow this procedure:

1. Press the P-key (opens the menu levels).
2. Press the key F5 (INIT-Parameter).
3. Press the key F1 (enter seam name).
4. The keys of the ten-key pad are occupied with letters, too. Each letter is shown on its key with a color (blue, orange, green). Press one of the keys F1...F3 together with a number key, to enter the desired letter (F1 blue, F2 orange, F3 green). Examples: A = F1 + 1; N = F2 + 5; U = F3 + 7.
5. Press the arrow keys to switch to the next or prior letter.
6. Press the P-key to terminate the entering and save the seam name.

### 2.1.6 Delete seams

An existing seam can be deleted.

**ATTENTION:** If a seam is used in several programs, it will be deleted in all programs. The deletion of a seam can not be undone.

1. Press the P-key.
2. Press F5.
3. Press F5.
4. Enter the number of the seam to be deleted.
5. Press the P-key to delete the seam.

## 2.2 Seam functions (P-F2)

	Center knife	cuts the pocket between the seams; if the center knife is disabled, the mitre knife will be disabled automatically <i>ВЕРХНИЙ НОЖ</i>
	Tab knife	cuts the pocket edges; if the center knife is disabled, the tab knife will be disabled, too <i>ПРСРУБКА НИЖНЕГО НОЖА</i>
	Stacker	stacks the sewed parts automatically <i>СБРОС ГОТОВЫХ ИЗДЕЛИЙ</i>
	Vacuum (option)	keeps the parts in the insertion station, until the main clamp is closed <i>ПРИЖИМ ЛАПКИ ПОСЛЕ 2 ИЛИ ВМЕСТЕ</i>
	Vylene (option)	automatic supply with vylene <i>ПОДАЧА КРАЯ</i>
	Stamp	fixes the parts in the insertion station (3rd hand) <i>ПРИЖИМ МАТЕРИАЛА</i>
	Piping blowing (option)	piping is blown to the folder, to prevent a snapping during insertion; should be enabled sewing thin parts <i>НЕТ</i>
	Folder up after seam end	increase of the production speed; earlier insertion of new parts is possible <i>ОБРЕЗКА И ПОДНЯТИЕ ПОЛЕ ПШИВА</i>
	Flap clamp left	necessary if additional parts to the piping are inserted (e.g. pocket bag, facing strips) <i>ОТУСКАНИЕ ПРИЖИМАЮЩЕЙ ЛЕВОЙ ЛАПКИ</i>

### 2.3 Seam parameters

Several seam-depending machine processes can be set:

1. Press the P-key.
2. Press F3.
3. Select the desired seam parameter using the arrow keys.
4. Press ENT-key.
5. Enter the desired value.

	Flap clamp right like flap clamp left (see above) ОПЕКАНИЕ ПРИЖИМНОЙ ПРАВОЙ АЛТКИ
	Seam shape trapeze jacket breast welt production; left seam longer than right one АВЕРБИИ УГОЛ ПРОРЕЗКИ КАРМАНА
	Seam shape trapeze trousers left needle shorter than right one ПРАВИИ УГОЛ ПРОРЕЗКИ КАРМАНА
	Seam form parallel both needles work parallel ЛЕНТ ПРОРЕЗКИ НОЖКА (ПРОБИВКИ, Δ30°
	Seam shape sloping pocket right left seam with offset to the right one КАРМАН НА УСКРОСЕК ПРАВИИ
	Seam shape sloping pocket left left seam with offset to the right one; mirrored to the right сloping КАРМАН НА УСКРОСЕК АВЕРБИИ
	Piping pulling through (option) turns the overlap of the piping (only during piping) ПАЗАВУЖЕНИЕ ПРИЖИМНЫХ ПЛАСТИ
	Photo cell left necessary during sewing of left flap КАРМАН КАРМАНА (ЛЕВАЯ СТОРОНА)
	Photo cell right necessary during sewing of right flap КАРМАН КАРМАНА (ПРАВАЯ СТОРОНА)
	Positioning point front calculation point for the seam start during sewing without flap
	Positioning point middle calculation point for the seam start during sewing without flap ОПРЕДЕЛЕНИЕ МЕСТА / КРЕСТ
	Positioning point rear calculation point for the seam start during sewing without flap
	Zipper scissor during sewing an endless zipper, this function gives a НА МОДНИКАХ МОЖНО ОПЕРАТОР НОВАНИИ stopcommand to the machine to allow the cutting of the zipp ПО ПАЗМЕРУ
	Seam backing Tack length at seam start and seam end ЗАКРЕПКА ШИВА
	Stitch condensing Stitch length at seam start and seam end. ЗАТАНТЛИВАНИЕ ШВА